


EAN: 4015474135154
static.hansa.com/01402273

Náhradné diely

SP01402173



	Názov	Kód
1	Ovládacia rukoväť, L=110 Chróm Ukončené	01580076
1	Ovládacia rukoväť, L=86 mm Chróm	01580073
1.1	Skrutka, M5x8, SW2.5	59904755
1.2	Klzné puzdro	59904778
1.3	Záslepka Sivá	59912112
2	Krytka Chróm	59913068
3	Skrutka, M50x1, SW45	59913069
3.1	O-krúžok, d 48x2	59913072
4	Kartuš, 4.8 eco	59904601
4	Kartuš, 4.8 Eco-Top	59911431
4.1	Hot water limiter	59904759
5.1	Ovládacie tiahlo Chróm	59913067
5.2	Spojovací diel tiahla	59904624
5.3	O-krúžok, 42x3.5	59904764
5.5		59904765
5.6	Skrutka, M8x1, SW13	59904766
5.7	Upevňovací set	59910749
5.8	Potrubie	59913070
5.11	Upevňovacia skrutka, M8x1, L=140	59912474
6	Aerator, M24x1 STD HC A Chróm	59902366
6	Aerator, M24x1 (2011-)	59913739
6.1	Aerator, M22/24 A	59902081
7	Vypúšťací ventil umývadla Chróm	59904620
N.I.	Podložka s očkom pre retiazku	59902219
N.I.	Flexibilná hadička	59913071
N.I.	Kľúč, SW45/SW50	59905190