


EAN: 4015474184978
static.hansa.com/51722178

Náhradné diely

SP51712173



	Názov	Kód
1	Ovládacia rukoväť, 70 mm	59913331
1.1	Skrutka, M5x35	59913299
1.4	O-kružok, d 3x1.5	59913100
1.5	Klobúk,krytka Chróm	59913332
1.5	Klobúk,krytka Čierna Ukončené	59913333
1.5	Klobúk,krytka Biela Ukončené	59913334
2	Krytka Chróm	59913364
2.1	Trecí krúžok	59913363
2.2	O-kružok, d 38x2	59913212
3	Skrutka, M4x1, SW34	59913365
4	Kartuš, 3.5 Eco	59912324
4	Kartuš, 3.5 Classic	59913075
4.1	Temperature adjustment limiter	59912325
4.2	O-kružok, d 28.24x2.62 Ukončené	59912590
4.4	O-kružok, d 10.10x1.60 Ukončené	59905072
5.1	Tiahlo s guľovým čapom Chróm	59913362
5.2	Spojovací diel tiahla	59904624
5.3	O-kružok, d 36.09x d 3.53	59913396
5.3	Gumové tesnenie	59914591
5.5		59904765
5.6	Skrutka, M8x1, SW13	59904766
5.7	Upevňovací set	59910749
5.8	Flexibilná hadička, L=500, G3/8-M10x1	59911767
5.8	Spojovacie potrubie, M10x1, L=480	59913368
5.9	O-kružok, d 7.65x1.78	59902337
5.12	Upevňovacia skrutka, M8x1, L=140	59912474
6.1	Aerator, M18.5x1, TJ	59913366
6.2	Kľúč k aerátoru, M18.5	59913367
7	Vypúšťací ventil umývadla Chróm	59911441
N.I.	Kľúč, SW30/34	59912108