


EAN: 4015474253872
static.hansa.com/52450177

Pièces de rechange

SP52450173



	Nom	Code
1	Levier Chrome	59913840
1	Levier Chrome	59914629
1.1	Vis, M5x8, SW2.5	59904755
1.3	Capuchon Gris	59912112
2	Chape, 33x3 mm Chrome	59912504
3	Écrou de maintien, M40x1	1003409V
4	Cartouche, 3.5 Eco	59912324
4	Cartouche, 3.5 Classic	59913075
4.1	Temperature adjustment limiter	59912325
4.3	Joint, d 28.24x2.62 Arrête	59912590
4.4	Joint, d 10.10x1.60 Arrête	59905072
5.1	Écrou de connexion, G3/4, AF30	59902230
5.2	Connecteur	59913400
5.3	Joint, 23.9x15.2x2	59902689
5.4	Clapet anti-retour	59905714
5.5	Mamelon de fil, G1/2xM18x1	59911384
6	Excentrique, G3/4xG1/2 Chrome	59904793
6.1	Rosaces Chrome	59913432
6.2	Silencieux	59904792
6.3	Connecteur excentrique, G3/4xG1/2, DN15	59910254
6.4	Rosace Chrome	59912651
N.I.	Clef, SW30/34	59912108