


EAN: 4015474094550
static.hansa.com/52482207

Náhradné diely

SP52482203



	Názov	Kód
1	Ovládacia rukoväť Chróm	59913903
1	Ovládacia rukoväť Chróm	59914629
1.1	Skrutka, M5x8, SW2.5	59904755
1.3	Záslepka Sivá	59912112
2	Krytka, 33x3 mm Chróm	59912504
3	Prítlačná matica, M37x1, AF30	59912111
4	Kartuš, 3.5 Eco	59912324
4.1	Temperature adjustment limiter	59912325
4.3	O-krúžok, d 28.24x2.62	59912590
4.4	O-krúžok, d 10.10x1.60	59905072
5.1	Tesnenie sada	59912514
5.2	Vymedzovacia podložka Chróm	59912516
5.3	Tesnenie, 43x37x3	59912506
5.4	Podložka	59910008
5.5		59904765
5.6	Skrutka, M8x1, SW13	59904766
5.7	Upevňovací set	59912113
5.8	Flexibilná hadička, L=430, G3/8-M10x1	59912515
5.9	O-krúžok, d 7.65x1.78	59902337
5.10	Tesnenie, 9.5x14.4x2	59912551
5.11	Upevňovacia skrutka, M8x1, L=140	59912474
6	Výtokové rameno Chróm	59912513
7	Aerator, M24x1 STD HC A Chróm	59902366
7	Aerator, M24x1 A (2011-) Chróm	59913740
7.1	Aerator, M22/24 A	59902081
N.I.	Klúč, SW30/34	59912108