


EAN: 4015474165335
static.hansa.com/57082201

Pièces de rechange

SP57092201



	Nom	Code
1	Levier Chrome	59913090
1.1	Pince à ressort	59913091
2	Anneau décoratif	59913088
2.1	Joint, d 40x2	59911507
3	Vis, M44x1 AF34	59913089
3.1	Socket wrench, SW34	59913092
3.2	Bague entretoise	59913096
4	Cartouche, 3.5 Joystick	59913051
4.1	Douille entretoise	59913093
4.4	Joint, d 10.10x1.60 Arrêté	59905072
4.5	Joint, d 28.24x2.62 Arrêté	59912590
5.1	Tirette de vidage Chrome	59912527
5.2	Joint	59904624
5.3	Joint, 43x37x3	59912506
5.5	Fixing plate	59904765
5.6	Vis, M8x1, SW13	59904766
5.7	Ensemble de fixation	59910749
5.8	Flexible d'alimentation, L=430, G3/8-M10x1	59912515
5.9	Joint, d 7.65x1.78	59902337
5.10	Joint, d 32x2	59912803
5.12	Vis, M8x1, L=140	59912474
5.13	Filtre à impureté	59911684
5.14	Limiteur de debit, 8L/min	59913095
6	Aérateur et clé, 6 l/min	59913094
7	Vidage Chrome	59904620
N.I.	Clé pour aérateur	59913757