


EAN: 4015474254350
static.hansa.com/01680174

Pièces de rechange

SP01680174



	Nom	Code
1	Levier Chrome	59913831
1.1	Vis, M5x8, SW2.5	59904755
1.3	Capuchon Gris	59912112
2	Chape Chrome Arrête	59912797
3	Vis, M40x1, SW34	59913834
4	Cartouche, 3.5 Eco	59912324
4	Cartouche, 3.5 Classic	59913075
4.1	Temperature adjustment limiter	59912325
4.3	Joint, d 28.24x2.62 Arrête	59912590
4.4	Joint, d 10.10x1.60 Arrête	59905072
5.1	Écrou de connexion, G3/4, AF30	59902230
5.2	Connecteur	59913400
5.3	Joint, 23.9x15.2x2	59902689
5.4	Clapet anti-retour	59905714
5.5	Mamelon de fil, G1/2xM18x1	59911384
6.1	Rosaces Chrome	59912652
6.2	Silencieux	59904792
6.3	Connecteur excentrique, G3/4xG1/2, DN15	59910254
6.5	Rosace Chrome	59912651
N.I.	Clef, SW30/34	59912108