


EAN: 4015474162884
static.hansa.com/57102201

Náhradné diely

SP57102201



	Názov	Kód
1	Ovládacia rukoväť Chróm	59913090
1.1	Spring clip	59913091
2	Dekoratívne krúžok	59913088
2.1	O-krúžok, d 40x2	59911507
3	Upevňovacia skrutka, M44x1 AF34	59913089
3.1	Socket wrench, SW34	59913092
3.2	Dištančný krúžok	59913096
4	Kartuša, 3.5 Joystick	59913051
4.1	Spacer sleeve	59913093
4.4	O-krúžok, d 10.10x1.60 Ukončené	59905072
4.5	O-krúžok, d 28.24x2.62 Ukončené	59912590
5.7	Upevňovací set	59913479
5.7	Upevňovací set Ukončené	59913250
5.8	Flexibilná hadička, L=600, G3/8-M10x1	59913249
5.9	Flexibilná hadička, L=590, G3/8-M10x1 Ukončené	59913166
5.10	O-krúžok, d 7.65x1.78	59902337
5.11	Tesnenie, 9.5x14.4x2	59912551
6	Aerator, M24x1 STD HC	59913741
6.1	Klúč k aerátoru, M24x1	59913134