


EAN: 4015474139749  
[static.hansa.com/57742101](http://static.hansa.com/57742101)

## Ersatzteile

### SP57742101



	Name	Art.-Nr.
1	Hebel, 50 mm, d 7 mm Chrom	59913097
1.1	Schraube, M5x25, SW 2,5	59913099
1.4	O-Ring, d 3x1,5	59913100
1.5	Abdeckkappe Chrom	59913098
2	Abdeckkappe Chrom	59912110
3	Gegenmutter, M37x1, AF30	59912111
4	Kartusche, 3,5 Eco	59912324
4	Kartusche, 3,5 Classic	59913075
4.1	Temperaturanschlag	59912325
4.2	O-Ring, d 28,24x2,62	59912590
4.4	O-Ring, d 10,10x1,60	59905072
5.1	Anschlussmutter, G3/4, AF 30	59902230
5.2	Sitz, 1/2"L	59904618
5.3	Dichtung, 23,9x15,2x2	59902689
5.4	Rückflussverhinderer	59905714
6.1	Rosette	59913105
6.2	Schalldämpfer	59904792
6.3	Exzenter-Anschluss, G3/4 x G1/2	59910254
6.4	Abdeckhülse	59913106
7	Auslauf Chrom	59913102
7.1	O-Ring, 31,00 x 1,50	59913104
7.2	Schraube, M6 x 80	59913103
8	Umsteller, automatisch Chrom	59913101
N.I.	Schlüssel, SW 30/34	59912108